





Porting (Triple pumps)										
	Code	00	36	11	37	Code	27	51	05	50
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3
	Code	43	62	52	25	Code	42	24	53	60
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3
	Code	23	45	49	59	Code	47	13	04	46
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3
	Code	59	40	48	10	Code	38	01	22	34
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3
	Code	08	31	20	30	Code	17	18	02	16
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3
	Code	28	32	19	07	Code	29	09	21	33
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3
	Code	26	61	46	44	Code	54	55	06	15
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3
		39	35	12	03	Code	63	14	57	41
	P2	P3	P3	P3	P3	P2	P3	P3	P3	P3