

MODEL CODES

EDITION III



Linde Hydraulics Corporation


5089 West Western Reserve Road

Canfield, Ohio 44406

Telephone: (330) 533-6801

Fax: (330) 533-2091

Model Codes for M-Series Open Loop Pumps



- NOTES:** (1) If codes are not used, insert the letter “X”.
 (2) If a unit is a **special execution**, insert “S” at the end of the code description.
 (3) Standard MPR includes both, LS and DR. When used as LS, DR acts as pressure cut off. When used as DR, LS is blocked.